(Optional) Transmitter Programming

Adding a Transmitter

1) If operator is in RUN mode, press CAL/RUN [CAL RUN] to enter calibration mode.
2) Press SCROLL [SCROLL] (up or down) until display reads "LEARN NEW XMTR? " **Figure 11**.
   • This question along with the instruction "HIT SET FOR YES" will continuously pan across the display window. (Pressing SCROLL or CAL/RUN will cancel the operation.)
3) Press SET/CLEAR [SET CLEAR].
   • Display will read "PUSH XMTR BUTTON TWO TIMES TO LEARN XMTR."
4) Press Transmitter button two times.
   • The display will read "XMTR ___LEARNED." Where it assigns a random number between 1 and 255 to the transmitter. That transmitter is entered and ready to operate the door. (Label/mark the transmitter.)
5) Press SCROLL [SCROLL] (up or down) to move on to another menu item, or CAL/RUN [CAL RUN] to exit the CAL mode.

Removing Individual Transmitter

1) If operator is in RUN mode, press CAL/RUN [CAL RUN] to enter calibration mode.
2) Press SCROLL [SCROLL] (up or down) until display reads "REMOVE XMTR? " **Figure 12**.
   • This question along with the instruction "HIT SET FOR YES" will continuously pan across the display window. (Pressing SCROLL or CAL/RUN will cancel the operation.)
3) Press SET/CLEAR [SET CLEAR]
   • A menu displaying the available transmitter numbers will appear. Press SCROLL [SCROLL] (up or down) to cycle through the menu to the number of the transmitter to be removed. (Pressing CAL/RUN will cancel the operation.)
4) Press SET/CLEAR [SET CLEAR]
   • The transmitter is removed.
5) Press SCROLL [SCROLL] (up or down) to move on to another menu item, or CAL/RUN [CAL RUN] to exit the CAL mode.

Figure 11

Figure 12

Figure 13

Removing All Transmitters

1) If operator is in RUN mode, press CAL/RUN [CAL RUN] to enter calibration mode.
2) Press SCROLL [SCROLL] (up or down) until display reads "REMOVE ALL XMTRS" **Figure 13**.
   • This question along with the instruction "HIT SET FOR YES" will continuously pan across the display window. (Pressing SCROLL or CAL/RUN will cancel the operation.)
3) Press the SET/CLEAR [SET CLEAR] key.
   • The display will read "ARE YOU SURE."
4) Press the SET/CLEAR [SET CLEAR] key.
   • All transmitters are removed.
5) Press SCROLL [SCROLL] (up or down) to move on to another menu item, or CAL/RUN [CAL RUN] to exit the cal mode.

RSX ®
Standard Duty Commercial Operator